



How to Auto Scan

Samsung

If you have a D.Menu button in the middle of the remote:

1. Press the D.Menu button
2. Highlight the satellite picture
 - a. Press Enter/OK
3. Go to Auto Store
 - a. Press Enter/OK
 - b. Press Enter/OK again
4. When the setup is complete
 - a. Press Exit
5. Auto tune complete

If you have TV/DTV button located at the top of the remote:

1. Press the CHLIST button
2. If you have many channels listed they are currently in digital mode. Go to **Step 4.**
3. If you only have a few channels
 - a. Press the TV/DTV button at the top of the remote
 - b. Go to **step 4.**
4. Press Menu
5. Scroll to the Digital Menu ICON
6. Press select
7. Scroll to Digital Channel and select
8. Go to Auto Store
 - a. Press Enter/OK
 - b. Press Enter/OK again
9. When the setup is complete
 - a. Press Exit



10. To view all the channels press the CHLIST button on the remote control

11. Auto tune complete

If you have a TV button located at the top of the remote:

1. Press the channel **1** button on the remote control.
2. Press the INFO button on the remote control
 - a. The number **1** will appear on the screen with either **ATV** or **DTV**
 - b. If the screen shows **DTV** go to **step 3**.
 - c. If the screen shows **ATV** press the channel **1** again on the remote to switch to digital. Go to **step 3**.
3. Press the Menu button
4. Scroll through the options using the arrow buttons until the satellite picture is highlighted.
5. Press select
6. Scroll down to Auto Store
7. Press select
8. From the Auto Store menu select Digital
9. Press select

Note: If the menu comes up with Air and Cable as an option select Air and it will bring you to the option to choose Digital.

10. When the setup is complete

- a. Press exit

11. To secure the channel scan press the CHLIST button on the remote control.

12. Auto scan complete



Sony

1. Press the Menu Home Button on remote control
2. When the menu pops up use the arrow keys and select Settings by pressing the middle circle button (enter)
3. From the menu that appears use the arrow button to the Setup Option
 - a. Press enter
4. A screen will appear asking permission to Start the Initial Setup Now
 - a. Arrow over to the OK option
 - b. Press Enter
5. Select English under the Language option
 - a. Press OK
6. Select Home press OK
7. The process may take up to 50 minutes to complete
8. Press ok
9. Wait until all stations are found, then the TV will revert back to normal stations.




VIZIO

1. Press the INPUT button on your remote to view your current input source. The TV (coaxial cable) input must be selected. This may appear as “TV,” “ANT,” or the channel and call letters of a station.
2. If the TV input is not selected, press INPUT until the TV input mode is selected.
3. Open the on-screen menu and select TV or Tuner option. (This varies by model.)
4. Highlight Tuner Mode and select the correct option:
 - a. Cable—direct from the wall cable TV, or a cable or satellite box connected to the TV with coaxial cable
5. Select Auto Search or Auto Channel Scan. (This varies by model.)
6. When the search reaches 100% complete, exit to the menu.
7. Check the available channels:
 - a. Antenna or direct-from-wall cable—Press the Channel Up and Channel Down buttons on your VIZIO TV remote to view the available channels.

Panasonic

1. Press the TV button on the top of the remote
2. Select DVB > press OK
3. Press the Menu button
4. Scroll down to setup
5. DVB tuning menu
6. Press ok
7. Go to Auto Setup option
8. Ignore message that pops up:



9. Press ok to get to the Setup for the auto scan.
10. The TV will automatically scroll through the channels (this may take about 3 minutes)
 - a. **Do not** push any buttons during the scan
11. Wait until all stations are found, then the TV will revert back to normal stations.



LG

1. Press the Menu button on the remote control.
2. Channel will be highlighted
3. Press Enter
4. Go to Auto Tuning
5. Press Enter
6. Arrow up to Start press OK
7. Press Enter
8. The TV will complete the Auto Scan process.